

## USB&AC Powered LED Walking Stick / Alarm / FM Scan Radio

Unit size: 15.4 \* 3.8 \* 73.7CM (folded); 96.50CM (unfolded)

Unit weight: 325g

### Working Principle:

This product adopts the high quality radio circuit with high sensitive FM radio. The build-in battery can be recharged by standard USB 5V cable then provide the power for LED lighting, LED flashing, alarm, and radio.

### Functions:

1. High sensitive FM radio.
2. LED lighting and flashing.
3. Alarm function for emergency.
4. Standard USB 5V charge the build-in rechargeable Li battery 3.7V 500MAH.
5. Adjustable high strength aluminium alloy shaft.

### Main Technical Parameters:

#### 1. Radio

Sensitivity of the FM	Better than 10uV
Reception scope of the FM	88-108MHZ (normal), 76-90 MHZ (Japan)
The audio frequency output power	More than 100mW
Radio working time after fully charged	More Than 6 Hours

#### 2. Lighting

The max luminous of 4 pieces LED	More than 15lm
Lighting time after fully charged	More than 12 hours

#### 3. Charged

Input Voltage	5—5.3V
Charging Connector	DC plug $\phi 3.5 * \phi 1.1$
Fully Charged Time by 5V Input	About 3 hours

### Operation method

#### 1. Adjust the height.

Slacken the locking ring a couple of turns. Push in the sprung button and slide the telescopic shaft to the desired length. For your safety, please ensure button is fully located in one of the holes and tighten the height adjuster locking ring to secure a safe lock.

#### 2. LED Lighting, Flashing and Alarm.

LED switch models: White LED Lighting --- White LED Lighting + Red LED Flashing ---OFF---100dB alarm + Red LED Flashing

### 3. Reception of FM Radio

- (1) Turn on the radio power switch, then press the key "scan forward" & "scan backward", to select the radio program required.
- (2) Press the key "volume up" & "volume down", to adjust the volume required.
- (3) This unit adopts telescoping antenna to receive signal for FM, when the signal is weak, you can change the direction of the antenna to find the optimal position, which can improve the radio reception.

### 4. Charge

Insert the USB male head of the connect cable into the USB hole of computer or adaptor, and the other DC connector into the unit, the power can charge into the battery of this unit, also the red indicator is on, if the battery fully charged, the red indicator will be dead.

### Cautions

- (1) Don't light at eyes directly so as not to hurt the eyes.
- (2) Don't put this unit in moist place or dip it in water.
- (3) The alarm enables the user to attract attention in emergency, but don't turn it on if everything is fine because the loud sound will scare the elder or baby.
- (4) Don't impact the stick heavily due to it will damage the plastic and electronic parts, then the function will be lost.

